


Servicing your Method products

Cleaning your Method bins


- Clean with a soft cloth
- Use a non-abrasive detergent
- Do not put lids in a dishwasher
- Rinse touch lids under a tap and scrub with a soft bristled brush

Cleaning your Precyclers


- Dishwasher safe
- Use a non-abrasive detergent
- Clean or dust with a dry soft cloth




How to fit a new Twenty or Sixty bin liner




1. Remove lid, place liner in bin, pushing to the bottom. Wrap liner around bag retainer edge.



2. Pull excess liner to the front of the bag retainer. Bunch and twist excess liner together.



3. Tuck excess liner through slot and back into main cavity of the bin. Place on lid.



4. Place on lid. The liner will stay in place for easy servicing and with no visible liner.

How to service a Twenty bin



You can tip contents from a Twenty bin into a larger bin for quick servicing using the handle on the back of the Twenty bin.